

## Anbauanleitung/Sicherheitshinweise LED Blinker „PEN HEAD“ Mounting and safety instructions LED turn indicator „PEN HEAD“

Vielen Dank für den Kauf eines HIGHSIDER Produktes. Unsere Leidenschaft zum Motorradfahren finden Sie in jedem unserer HIGHSIDER Produkte wieder. Wir wünschen Ihnen allseits eine gute und sichere Fahrt mit Ihrem neuen HIGHSIDER Produkt aus dem Hause Paaschburg & Wunderlich GmbH.

Lesen Sie diese Anbauanleitung vor der Montage sorgfältig durch.

Nur bei fachgerechter Montage und Anschluss ist die gesetzliche Gewährleistung erfüllt. Die Leuchtrichtung muss parallel zur Fahrbahn und zur Fahrzeugängsachse weisen. Das Modul darf nicht geneigt verbaut werden. Dieses Lichtmodul ist ausschließlich zur Montage an Motorrädern zulässig und erfüllt bei ECE konformer Befestigung die europäischen Vorschriften. Es ist kein Eintrag in die Fahrzeugpapiere oder mitführen etwaiger Dokumente notwendig.

**Beauftragen Sie Fachpersonal mit der Montage, sollten Sie selber unsicher sein! Schauen Sie niemals direkt in das Licht der LED's!**

- 1) Vor der Montage klemmen Sie die Batterie ab. Achten Sie darauf, dass ihr Fahrzeug sicher steht. Vor dem festen Einbau empfehlen wir, einen Funktionstest der Leuchten durchzuführen.
- 2) Das rote Kabel (Blinker) wird an Plus (+), das schwarze Kabel an Masse (-) angeschlossen. **ACHTUNG:** Nur an 12V DC Bordnetz anschließen! Niemals die LED-Einheit ohne die mitgelieferten Elektronikbausteine anschließen! Bei Nichtbeachtung bzw. technischen Veränderungen der Leitung und/oder den Steckverbindungen erlischt jeglicher Garantieanspruch!
- 3) Verlegen Sie alle Kabel fachgerecht. Kabel nicht knicken. Lose Kabelenden gut isolieren!
- 4) Die Montage der Blinker geschieht paarweise! Achten Sie darauf, dass die Blinker gut sichtbar sind und nicht durch Taschen oder ähnliches verdeckt werden.
- 5) Bei Fahrzeugen mit CAN-Bus System, oder auch mit ABS-System, kann es aufgrund des geringeren elektrischen Widerstand des LED Blinkers zu Fehlermeldungen kommen. In diesem Fall schafft ein parallel geschalteter Widerstand Abhilfe.
- 6) **ACHTUNG:** Nach der Montage muss die korrekte Funktionsweise des ABS-Systems und /oder des CAN-Bus Systems überprüft werden!
- 7) Sollte die Blinkfrequenz zu hoch sein, müssen entweder Widerstände parallel zum Blinker angeschlossen oder ein lastunabhängiges Blinkrelais im Bordnetz verbaut werden. Bei Verwendung von Widerständen muss auf gute Wärmeabfuhr geachtet werden.  
**ACHTUNG:** Diese Maßnahmen können verhindern, dass sich bei Ausfall eines Blinkers die Blinkfrequenz verändert. Daher muss die Blinkfunktion vor jeder Fahrt überprüft werden!  
Finden Sie passende Blinker-Verlängerungen, Leistungswiderstände, elektronische Blinkrelais, Adapterkabel und anderes Zubehör in unserem Webshop!

Thank you for buying a HIGHSIDER product. Because of our passion for motorcycles all our products are designed to meet your needs as a motorcyclist. We wish you always a safe and pleasant ride with your new HIGHSIDER product from Paaschburg & Wunderlich GmbH.

Before installation please read this manual carefully.

The installation shall be conducted according to the ECE standard and by a qualified person. If the installation violates the ECE standard the liability for the product is lost. The emitting direction of the light shall be oriented parallel to the ground and the longitudinal axis of the vehicle. Do not install the modules inclined. This light modules is approved for the use on motorcycles. The product complies with the current ECE standard. This means no registration or carriage of documentation is needed when installing it onto your motorcycle. **If uncertain about the installation please hire a qualified person. Never look into the light of the LED's!**

- 1) Disconnect the battery from the electric system and assure that your motorcycle stand solidly on ground. Before installation a functional test of the indicator is recommended.
- 2) Connect the red cable (indicator light) to plus (+) and the black cable to ground (-). **CAUTION:** Only connect to 12V DC power supply! Never connect the LED module without the black electronic modules! Any modification or change of the cables or connectors or connecting the indicators without the electronic module will terminate the guarantee.
- 3) All cables must be laid out carefully and in a professional manner. Prevent sharp bending of cables. Open cable ends must be insulated.
- 4) Always install pairs of indicators. Make sure no accessories like bags etc. affect the light distribution of the indicator.
- 5) Due to the reduced electrical resistance of the LED modules, vehicles equipped with CAN-bus system or in some cases ABS system, may need the installation of an additional resistor (in parallel) to work properly.
- 6) **CAUTION:** After installation, the proper function of the ABS system and/or CAN-bus system must be checked!
- 7) If the indicating frequency is too high additional resistors installed in parallel to the indicator or the use of a load independent indicator relay will remedy the problem. Make sure to install the resistors with a maximum of heatsink/dissipation.  
**CAUTION:** Installing additional equipment can cause that no change of the indicating frequency occurs in case of failure of one indicator. Due to this fact, a check of the indicating function needs to be performed before each ride!  
Find useful additional accessories like stem extensions, resistors, electronic relay, adapter cable and other equipment in our webshop!

Kabelbelegung:  
Nur an 12V DC Bordnetz verwenden!  
Niemals ohne die schwarzen Elektronikbausteine anschließen!

schwarz – Masse (-)  
rot – Blinker (+)

Cable connection:  
Connect to 12V DC only!  
Never connect without the black electronic modules!

black – ground (-)  
red – indicator (+)

Weitere HIGHSIDER Produkte finden Sie auf: [www.highsider-germany.de](http://www.highsider-germany.de)

**Scan it !!!**



### Haftungsausschluss und Garantiebestimmungen:

Bei unsachgemäßer Handhabung, Montage oder Verwendung des Gerätes erlischt jeglicher Garantie- und Gewährleistungsanspruch. Aufgrund der Nicht-Überprüfbarkeit der sachgemäßen Anwendung übernimmt die Firma Paaschburg und Wunderlich GmbH keine Haftung für direkte oder indirekte Schäden bzw. Folgeschäden die aus dem Betrieb des Gerätes entstehen. Zu diesen zählen unter anderem: Personen-, Finanzielle- und Sach-schäden jeglicher Art. Die Verwendung im öffentlichen Verkehr geschieht auf eigene Gefahr.

Paaschburg & Wunderlich GmbH, Am Alten Lokschnuppen 10a, D-21509 Glinde  
Tel.: +49 (0) 40 248 277-0; E-Mail: [sales@pwnonline.de](mailto:sales@pwnonline.de)

Alle Rechte, Änderungen und Irrtümer bleiben vorbehalten.  
09/2016 #203-180A

### Exclusion of liability and guarantee regulation:

In case of inappropriate use or installation of the device, all guarantee claims and liability for direct or indirect or subsequent damage become invalid. Paaschburg & Wunderlich GmbH is not liable for any damage resulting usage, installation or connecting of the device. In particular the liability on damage to person and financial loss is excluded. The use of the device in public traffic is at owner's risk solely.

Paaschburg & Wunderlich GmbH, Am Alten Lokschnuppen 10a, D-21509 Glinde  
Tel.: +49 (0) 40 248 277-0; E-Mail: [sales@pwnonline.de](mailto:sales@pwnonline.de)

All rights reserved. Changes and errors are excepted.  
09/2016 # 203-180A